GSM-Support ul. Dobrego Pasterza 102/5, 31-416 Krak·w
mobile +48 608107455, NIP 8133358609 REGON: 181081334
www.gsm-support.net

Infinity Box Dongle

Infinity-Box Dongle is World-famous "Chinese Miracle" software for MTK / MediaTek, etc. and "Chinese Miracle-2" software for MTK / MediaTek, SPD / Spreadtrum, RDA / Coolsand, etc. with access to support area (software, flash files, drivers, manuals, updates, bug-fixes, etc.)

NOW IN SET YOU WILL RECIVE CHINA MIRACLE RDA/MTK AND SPD ACTIVATIONS FOR FREE

Features:
Well known GSM and CDMA brands / models supported
"Chinese Miracle" MTK based brands / models supported
Standalone software (no Internet connection required)
SP-unlock: unlock (remove / clear) network, provider locks
Set network, provider locks
Read unlock codes
Flash read / write (high speed)
Write any part of Flash separately (firmware, customization, flex, map, file system (FFS), language pack)
Upgrade / downgrade firmware
Repair damaged IMEI
Remove / clear / read user / phone lock code
Reset to default / factory settings
Repair dead phones
Read Flash / EEPROM area backup
Repair software-related problems
Read unlock codes: network, provider codes, user / phone code
Empty board flashing (for example, after flash chip replacement)
Format file system
SCAT files read / write
Create security zone backup during critical operations
"Smart write" option, together with high-speed option flashing speed may be extremely high
Detect keyboard codes by flash file ("Keyboard codes detector")
Save operation process results in a Log file
Big flash files database for all World regions
Compact flash / EEPROM files format: flash / backup files internally packed and unpacked on the fly. That way you can save up to 50% of your Internet traffic (download small files from support area) and save a lot of disk space on your HDD
Counter for unlock / flash / other operations
Easy to use brand / model selection via "Shell"
Easy access to cables / pinouts information via "Cable selector"
Easy access to support area via automatic logon system and "Support manager"
Huge flash files database: firmware, language pack, flex, map, repair EEPROM, FFS files, etc., more than 20,000 files for different models
Documentation and manuals with step-by-step instructions
Multi-language User Interface (MUI): (Arabic, Czech, Spanish, Farsi, French, German, Indonesian, Italian, Polish, Portuguese, Romanian, Russian, Slovenian, Serbian, Thai, Turkish, Vietnamese)

"Chinese Miracle" module for MTK-based models - Features:

Automatic phone structure detection: this means that you can also service phones which is not shown in supported models list. Just find a pinout and make sure that your phone is based on MT62xx CPU and you will be able to flash / unlock / repair this phone.
Repair dual-SIM (dual-CPU) models: work with Rx_A/Tx_A, Rx_B/Tx_B pinouts to repair firmware for both CPU
Repair IMEI for single-SIM and dual-SIM models with different methods (MT6205, MT6223 dual configurations supported too)
Repair IMEI for single SIM/CPU models
Repair master IMEI (SIM-1) for dual-SIM (dual CPU) models
Repair slave IMEI (SIM-2) for dual-SIM (dual CPU) models
Repair master IMEI (SIM-1) for dual-SIM (single CPU) models
Repair slave IMEI (SIM-2) for dual-SIM (single CPU) models
Repair slave IMEI (SIM-3) for triple-SIM models
Automatic memory size detection
Direct SP-unlock phones with unknown firmware (auto-detection algorithm)
Direct unlock user code phones with unknown firmware (auto-detection algorithm)
Format file system: auto-detect FFS structure and size, backup FFS before format
Reset to defaults phones with unknown firmware (auto-detection algorithm)
Write / Read Flash for phones with unknown structure (auto-detection algorithm)
Write / Read EEPROM for phones with unknown structure (auto-detection algorithm)
Firmware version auto-detect
Automatic firmware version detection and save original firmware version information in Log file during flash / format
Language list auto-detect
Repair "Power-On problem" for MT6205, MT6208, MT6217, MT6218, MT6219, MT6223, MT6225, MT6226, MT6227, MT6228, MT6229, MT6230, MT6235, MT6238, MT6239, MT6253, MT6268 CPU based models after full flash without backup, erased flash, etc.
Repair / recalculate security area (five different security area types supported) to repair dead phones based on MT6223, MT6225, MT6226, MT6227, MT6228, MT6229, MT6230, MT6235, MT6238, MT6239, MT6253, MT6268 CPU
Upgrade / downgrade phone firmware
Unlock (remove / clear) network, provider locks
Read unlock codes: network, provider codes, user / phone code
Reset phone settings to defaults (factory state)
Empty board flashing (for example, after flash chip replacement)
Create security zone backup during critical operations
Repair software-related problems
Repair dead phones
"Flash File Manager": easy access to firmware information such as internal firmware name, language names, keyboard codes
Touchscreen calibration (repair phones with damaged touchscreen)
Repair "No licensed to produce" fault
Repair "Bad Software" fault (latest MT6223, MT6225, MT6226, MT6227 based models)
Repair "Code CRC Check Error" fault
Detect language names inside flash file
Detect keyboard codes inside flash file (for service menu, etc.)
Detect firmware version by flash file
Detect existing languages by flash file
Detect keyboard codes by flash file ("Keyboard codes detector")
Batch flash file rename, version detection, language detection, name conversion
Save operation process results in Log file
Huge and almost complete flash files database: firmware, repair EEPROM, FFS files, etc.
Estimated remaining flash read / write time indication
Documentation and manuals with step-by-step instructions

Note: To avoid any misunderstanding please check list of available functions for each supported model, different models have more or less functions, because of hardware / software limitations!

Supported models GSM - European series:
Obsługiwane modele GSM - seria Europejska
Nokia: DCT4 Plus ASIC11: 1202, 1203, 1208, 1209, 1650, 1661, 1661-2b, 1662, 1680c-2b, 2220s, 2320c-2b, 2330c, 2330c-2, 2600c-2b, 2610, 2610b, 2630, 2630c, 2680s, 2680s-2, 2720a-2, 2760, 2760h, 5030c (and other similar models) list of features
Aiko: 17G, 51G, 52G, 70w, 78G, 97G
Airam: M342
Aircel: 311, 411, 422, 466, G240, G301
Airness: Air99, MK99, Slide99
Airtel: Avvio-G200, Cordless_FGD8900, FGD9000, Pacetel-Cordless-L900, Telular
Ajanta: A1800, A1900, A2100, A3000, A4200, A5000, A52, Quartz, other
AK-Mobile: AK760i, AK900
Alcatel: 090, 103A, 103X, 104, 105A, 105X, 1060x, 106X, 108X, 109, 112, 113, 140X, 150, 1801, 203A, 203E, 203X, 2040G, 204X, 205, 206X, 208A, 208X, 209A, 209X, 213X, 214, 216X, 217D, 221A, 221X, 222A, 222X, 223, 228, 250, 252, 255A, 255DX, 255X, 280X, 282, 292, 296, 297, 300X, 301X, 303A, 303X, 304A, 304X, 305A, 305X, 306A, 306X, 310A, 310X, 311X, 315M, 322, 352X, 355A, 355DA, 355DX, 355X, 356, 358, 360A, 361, 362, 363A, 363X, 380X, 383A, 383X, 385,

385J, 4007X, 4010A, 4010D, 4010E, 4015X, 455, 505K, 505X, 506, 508A, 540, 543X, 565K, 565X, 585, 600A, 600X, 602, 606, 660A, 660X, 665, 668, 7040A, 7042D, 706A, 706X, 708A, 708X, 710, 710D, 710K, 7110, 799, 800, 802, 802Y, 803, 806, 807, 808, 808M, 809, 813, 813F, 818, 819, 828, 880, 888, 900, 901, 905, 907, AM01, B331, C700A, C700X, C701A, C701X, C707X, C717A, C717X, C820A, C825A, C825X, Crystal, E100x, E101, E15x_16x_25x, E201, E205, E207, E221, E227, E230x, EL09X, Elle-EL09X, Elle-N3A, Elle-N3X, F101, F115, F117, F121X, F122X, F123, F152, F153, F330X, F331, F344, GlamPhone-EL05A, I606, I650A, I650X, I780, I808, I818, I888, I898, I905, KR01X, Lava, Mandarina-Duck-MD01X, Mandarina-Duck-MD02X, Miss-Sixty, OT-1051D, OT-1060D, OT-1060X, OT-1062, OT-1063, OT152, OT-2040D, OT-316A, OT-316D, OT-316S, OT-6012A, OT-6012X, OT-918, S100, S107, S120, S121, S122, S210, S211, S215A, S215X, S218X, S319A, S319X, S320X, S321A, S321X, S520A, S520X, S521A, S521X, S621A, S621X, S626A, S626X, S680, T208, T255, T268, T355X, T66, V155, V212, V212C, V221A, V221X, V222A, V222X, V270, V345, V350, V555, V570A, V570X, V607A, V670A, V670X, V770A, V770X, VM575

Amplicom: M6000

Amstrad: S288

Angela: GTX85MV

Asiafone: AF501, AF502

Asus: J202, J206, J208, V66, V75, V80, other

AT-Telecom: Hi-Messenger

Audiovox: GPRS748, GSM609

Avio: 101, 102, 201, 203, 204, 205, 301, 403, A306, A6103, S505, other

Avvio: 103A, 203A, 209, 251, 410, 505, 530A, 768, 775, 778, 792, 795, 930A, G200, GD851p, GD852p, SN50, SN70, T519

Azumi: A1, F1, L1N, Q503, S101

BBK: i2288, i399, K202, K300, K322, S201, S202, other

Beeline: A100, A103, B2011A, B2011T, G3610, Pro, Pro-2, R221, Smart-3, Smart-4, Tab-Pro

Beetel: EC003, EC005

Bellwave: N77, other

BenQ: C36

BenQ-Siemens: A38, A500, A53, C30, C71A, CF51, CF61, CL71, E52, E61, EF51, EF61, EF71, M100, M220, M300, M305, M315, M350, M580, S660C, S700, S80, S81, S82, S88, SFG75, T33, T51, T66, Z2, other

Bess: SP500, SP770, VZ210, VZ219, VZ480, other

Bird: D515A, D611, D612, D615, D630, D650, D660, D670, D706, D716, D720, D730, D736, D760, F200, F300, F501A, F518, F527, K102, K298, S1120, S1180C, S1186, S160a, S198, S199, S230, S288, S299, S301, S302, S305, S306, S320, S570, S688, S699, S701, S710, S788, V09, V10, V5518+, V620, V708, V750, V788, V789, other

BlackBerry: 6230, 6720, 7100t, 7100v, 7100x, 7130c, 7130g, 7130v, 7230, 7290, 7730, 8100-Pearl, 8110-Pearl, 8210-Pearl, 8220-Pearl-Flip, 8300-Curve, 8310-Curve, 8520, 8520-Curve, 8700c, 8707v, 8800, 8830-World, 8900-Curve, 9000-Bold, 9500-Storm, 9530-Storm, 9630-Tour, 9700

Bleu: 151x, 245x, 251s, 251x, 253x, 255x, 351x, 354x, 355x, 450z, 453x, 454x, 456x, 466x, 471x, 476x, 550x, 551x, 555x, 651x, 651Z, 670x, 670z, other

Blu: Advance-4.0-A270a, Aria-II, Dash-D140K, Dash-JR-K, Dash-JR-TV-D140T, Jenny-TV-2.8, Life-Play-2, Q200, Studio-5.0, Studio-5.0-C-Mini, Studio-5.0-II-D532u, T200-Deejay, T210, T300, Tank-II-T192, Zoey-T166

BMobile: AX535, AX540, C612, C628, K106, K298, LQ310, S168, S750, TV9, X131, other

BSNL: EC005, G200CF

Coral: 100, 180, 200, 200FM, 225, 255, 266, 280, 300, 400, 400FM, 450, 500, 500FM, 550, 555, 620, 630, 640, 645, 655, 725, 850, other

Cordless-Phone: FC8050

Daewoo: D600, other

DBTel: J6

Digibee: BSNL-G200CF, G240

Dirland: E307, M881, P708, R100, X410

Doro: 338gsm, 611, 612, HandleEasy-326gsm, HandleEasy-328gsm, PhoneEasy-345gsm, PhoneEasy-409s, PhoneEasy-410gsm, PhoneEasy-410s, PhoneEasy-610

Elenberg: MT105, MT320, MT520, other

Elson: E800, ESL808, MP500, SL308, SL900

Emblaze: Sting6, Touch7

Emporia: Click-V32c

Etisalat: 211FM

Ezio: E300, E800, ESL808, MP500, SL308, SL900, other

Fly: 2040, 2040i, 2040L, 2060, 2080, B300, B400, B430, B600, B700, DS100, DS103D, DS105, DS110, DS110i, DS120, DS150, DS156, DS160, DS165, DS170, DS180, DS185, DS186, DS210, DS400, DS420, DS500, E100, E105, E110, E115, E120, E125, E130, E135, E140, E145, E147TV, E150, E160, E170, E171, E181, E185, E190, E300, E310, Ezzy, Ezzy3, FT10, G1, Hi-SLDR, Hummer-HT1, Hummer-HT2, IQ441, IQ4418, Levis-LV1, LX500, LX600, LX610, LX800, M100, M130, M140, MC100, MC105, MC120, MC130, MC150DS, MC160, MC165, MC170DS, MC175, MC180, MC220, MC300, MP100, MP220, MP300, MP400, MP500, MP600, MX200, MX200i, MX230, MX300, MX330, Q110, Q200, Q300, Q400, Q410, SL100, SL130, SL140DS, SL140i, SL200, SL300m, SL399E, SL400m, SL500i, SL500m, SL600, SL600-Vodafone, SLT100, ST100, ST300, SX100, SX200, SX210, SX215, SX220, SX225, SX230, SX240, SX300, SX305, SX310, SX315, TS107, V100, V180DS, V40, V50, V60, X3, X7, X7a, Z200, Z300, Z300a, Z400, Z500, other

Foxlink: Z302

Gallin: GM63

GeneralMobile: DST01, DST10, DST11, DST12, DST13, G333, other

G-Fone: 311-Aircel, 411-Aircel, 422-Aircel, 466-Aircel

GLP: 138GT

Gtran: N120, N150, N510

Hagenuk: DS300, Jazz, M628, other

Haier: G111, G30, HG-A8, HG-M150, HG-M151, HG-M161, HG-M306, HG-M307, HG-V70, M300, M500, S210, T757, Z1000, Z1600i, Z701S, Z702
Huawei: Acend-U30, C2205, C2285, C506, C6300, G20, G2800S, G330d, G3500, G3501, G3510, G3510m, G3510s, G3512, G3610, G3621L, G5010, G5500, G5510, G5521, G5720, G5730, G5760, G6, G6005, G610-U00, G6150, G6600, G6600D, G6603, G6608, G6609, G6610, G6610v, G6620, G6622, G7002, G7007, G7010, G7050, G7105, G7206, G7210, G7300, G7600, Honor-3C, Honor-HOL-U19, T128, T156, T158, T160L, T161L, T201, T202, T206, T208, T211, T261L, T330, T710, T711, Y220, Y221-1U22, Y320-U30, Y330, Y330-U01, Y330-U05, Y511-U30, Y520-U22, Y600-U20
Hyundai: H350, L480, MB-115, MB-121, MB-D125, MB-D130, MP318, MP510, MP718, MP728, MP738, MP880, W100, other
I-Mobile: 100, 101, 200, 2211, 222, 301, 306, 308, 313, 315, 318, 320, 360, 508, 510, 511, 516, 518, 520, 523, 530, 536, 600, 601, 602, 603, 604, 606, 608, 609, 609i, 610, 611, 613, 625, 626, 630, 901, 902, 903, BlackIce, CE0680, CE0889, CX-K809, IE3210, other
Innostream: Inno-900, other
INQ: Chat, Mini
Intex: 2x, 702, Alpha, Aone+, Aqua-3G, Aqua-4.5E, Aqua-A1, Aqua-I14, Aqua-i5, Aqua-i6, Aqua-I7, Aqua-Marvel+, Aqua-Power, Aqua-Power-HD, Aqua-Speed, Aqua-SX, Aqua-T2, Aqua-T4, Aqua-T5, Aqua-X, Aqua-Xtreme, Aqua-Y2, Aqua-Y2-Pro, Classic+, Cloud-Y13+, Cloud-Y4, Cloud-Y4+, Fame, Fame-301, Force, Force-2, Grand, Hunk, IN0315, IN1044, IN1107, IN1212, IN1212-Nano-Plus, IN1220, IN1224, IN2010, IN2020, IN2020E, IN2020FM, IN2020-Nano, IN2020-Nano2, IN2020QT, IN2022-Nano, IN2030, IN2030D, IN2030Dx, IN2040E, IN2040N, IN2044, IN2060, IN2080, IN2080E, IN2222, IN2233, IN2244, IN2266, IN3030, IN3050, IN3055, IN3060, IN3060D, IN3070, IN3070E, IN3080, IN3080E, IN3333, IN40, IN4040, IN4060, IN4400, IN4410, IN4415, IN4420, IN4420S, IN4444, IN4455, IN4460, IN4466, IN4470, IN4470N, IN4477, IN4488, IN4495, IN5000, IN5030, IN5040, IN5050, IN5544, IN6611-Ace, IN6622, IN6622i, IN6623, IN6633, IN6660, IN8810, iSmart, Jazz, Leo, Nano2, Nano-2x, Nano-Star, Neno2, Neo-201, Neo-V-Plus, P3, Platinum-Cube, Platinum-Dream, Platinum-Mini, Platinum-Ultra, Player+, Power+, Pride, Pride-LX, R2, Style-VX, T3, T4, Turbo-N, Y2-Pro, Yuvi-Pro, other
Karbonn: A065, A1+, A101, A109, A119, A11Star, A12+, A12Star, A14, A14+, A19, A19+, A1Plus-Super, A1Star, A2, A2+, A20, A240, A25, A25+, A26, A4, A40, A50s, A51+, A52, A52+, A5s, A6, A6MT, A7Star, A90s, A92, A92+, A92Star, A99i, K10, K101, K101Star, K102, K102+, K102Star, K103, K104Star, K110i, K111, K118, K121, K14, K18, K20Star, K217, K21Star, K22+, K222s, K25, K27Star, K2Star, K3+, K300, K32Star, K330, K331, K34+, K343, K350, K36+, K406, K443, K444, K444i, K445, K446, K447, K450, K451, K451+, K46+, K460, K478, K496, K51, K52+, K52Star, K541, K55+, K550, K56, K560, K57+, K570, K58, K595, K61, K62+, K63+, K650, K661, K695+, K70, K72+, K725, K73, K75, K75+, K76+, K77, K770, K7Star, K84, K85, K9, K9+, K90, K95, K96, K98, KC411, KC470, K-Phone1, K-Phone2, K-Phone5, Machone-S310, S2, S2+, S4+, ST52, Ta-Fone-A37, Titanium-Octane, Titanium-Octane+, Titanium-S10, Titanium-S12-Delite, Titanium-S19, Titanium-S2, Titanium-S2+, Titanium-S20, Titanium-S25, Titanium-S4+, Titanium-S5+, Titanium-S5-Ultra, Titanium-S6, Titanium-S8, Titanium-S9, Titanium-ST72, other
KN-Mobile: KN200, KN300, KN310, KN400, KN500
Konka: 169FM, A26M, A76, A76FM, C220, C612, C623, C623FM, C625, C628, C629, C635, C636, C676, C926, C966, D163, D165, D169, D225, D266, D280, D316, D363, D620, D770, E303, EC001, EC001FM, EC003, EC006, G208, K120, M5061, M520, M910, W990, other
KPN: One, Touch
Kyocera: C2500, E2500, E3500, E4600, S1600
Lanix: Kip, LX11, LX5, S106, X10, Z11
Lava: 252, 285, 405+, A10, A9, ARC02, Arc1+, Arc11+, Arc111, Arc12, Arc22, Arc9i, Arc-Lite, ArcOne, C11s, Dis128, Dis132, Disc-136, Discover132, Discover135, Discover-136s, i130S, Iris-245e, Iris-250, Iris-310s, Iris-352e, Iris-354e, Iris-356, Iris-402, Iris-404e, Iris-404-Flair, Iris-405+, Iris-410, Iris-415, Iris-503e, Iris-504Q, Iris-Fuel20, Iris-Style-300, KKT12, KKT14+, KKT20, KKT20+, KKT20i, KKT21, KKT21+, KKT22, KKT24, KKT25, KKT27, KKT27+, KKT27i, KKT27S, KKT29+, KKT30, KKT34, KKT34+, KKT41, KKT42, KKT9+, KKT-Lite+, KKT-Prime, M23, Neo, Spark10, Spark-285, other
Leady: C506, GT6107, MM10, MM95, X105, X501, other
Lenovo: 688, A1000-G-IdeaTab, A1000T, A3000-H, A316i, A319, A328, A330, A3300-GV, A332, A350, A390, A516, A536, A539, A7000, E300, E307, E520, i510, i60, i706, i908, i909, IdeaTab-A1000-G, K50, P50, P612, P618, P708, P710, S5, S533, S600, S62, S650, S850, S960, Shark-32, V707, V800, other
LG: 300G, A120, A155, A165, A290, B2000, B2050, B2060, B2070, B2100, B2150, B2250, C1100, C1150, C1200, C2200, C2500, C2600, C3300, C3310, C3320, C3400, C360, F2250, F2400, G1800, GB100, GB101, GB102, GB105, GB106, GB107, GB108, GB109, GB125, GB160, GB160a, GB160b, GB165, GB170, GB190, GB190a, GB190b, GS190, GS200, GS205, GX200, KE260, KE600, KE770, KE800, KE820, KE850, KE970, KF301, KF600, KG110, KG120, KG130, KG180, KG190, KG195, KG200, KG208, KG210, KG220, KG225, KG240, KG245, KG270, KG271, KG275, KG276, KG278, KG280, KG285, KG288, KG289, KG290, KG291i, KG295, KG296, KG300, KG320, KG370, KG375, KG70, KG90N, KM330, KM335, KP100, KP105, KP106, KP107, KP108, KP109, KP110, KP112, KP115, KP130, KP135, KP170, KP199, KP200, KP202, KP202i, KP210a, KP215, KP215A, KP220, KP230, KP233, KP235, KP320, L342i, L343i, ME770, ME850, ME970, MG100, MG101, MG105, MG110, MG120, MG125, MG160, MG161, MG165, MG170, MG180, MG225, MG230, MG235, MG280, MG296, MG320, MG370, S310, X330T, X335
Libercell: KT400, KT500, KT8800
Lobster: 485, 544, 575, S621
Maxx: 421, 845, A177, AX40, AX5, AX8-Race, MQ340, MQ430, MSD7, MX101, MX118, MX122, MX124, MX167, MX240, MX245, MX3, MX304, MX316, MX322, MX333, MX335, MX404, MX425, MX435, MX463, MX470, MX480, MX488, MX4e, MX5, MX513, MX533, MX534, MX552, MX713, MX745, MX845, other
Medion: 2860, MD-95100, MDMP1200, other
Megafon: CP10, Login+, Login2, S4, TDM15
Mi: 200, 250e
Micromax: 511x, A064, A065, A066, A068, A069, A074, A082, A089, A092, A093, A102, A102-Doodle-3, A104, A106, A110, A110Q, A114, A115, A116, A117, A120, A177, A200, A250, A290, A46, A47, A63, A69, A72, A74, A76, A77, A88, A89, A91, A92, A99, AD3520, AD4500, Canvas-110, Canvas-HD, D200, E581, E930, Funbook-Duo, G4, GC255, GC256, GC257, GC275, GC400, M116, M2, MMX310G, Neo-4, Q1, Q1+, Q2, Q3, Q3+, Q355, Q5, Q50, Q5FB, Q6, Q7, Q75, Q80, X008, X072, X084, X085, X088, X090, X091, X095, X096, X097, X099i, X101, X103i, X112, X113, X114, X115, X116, X117, X118, X11i, X122,

X1i, X1i+, X1i-Xtra, X1u, X200, X210, X211, X212, X215, X220, X222, X225, X226, X228, X230, X234C, X235, X2420, X249, X250, X251, X252, X253, X254, X258, X260, X261, X262, X263, X264, X265, X267, X270, X272, X280, X281, X2814, X282, X285, X287, X295, X2i, X2i+, X310, X321, X328, X329, X330, X332, X332-TV, X337, X340, X351, X353, X360, X361, X367, X368, X370, X395, X396, X414, X445, X446, X450, X455, X455i, X456, X458, X485, X50, X500, X501, X505, X510, X511, X555, X560, X600, X800, other
Modelabs: Airness-Slide99, Elite, MyWay-Slim, MyWay-Touch, V-Slide, V-Touch
Mojo: C200, Chat
Motorola: C113(a), C114, C115, C115i, C116, C117, C118, C119, C121, C122, C123, C136, C137, C138, C139, C140, C141c, C155, C156, C157, C168, C168i, C257, C261, E365, F3, F3-unlock, FX900P, V170, V171, V172, V173, V175, V176, V177, V690, V872, V878, W150, W150i, W170, W170C, W200, W205, W208, W209, W210, W212, W215, W218, W220, W355, W370, W375, W376, W377, WX160, WX161, WX180, WX181, WX260A, WX260X, WX265, WX280, WX288, WX290A, WX290X, WX295A, WX295X, WX390, WX395
Movistar: 731, Match, Onda, R791, Urban
MTS: 140, 352, 535, 547, 635, 982T, Basic, Qwerty, Smart-Start
My_Way: Modelabs-Slim, MW100, MW200, Touch
MyPhone: 1070, 3350, 3370, 6650, 6651, 6670, 6691, 8830TV, 8870, A818i, B21, B22, B23, B23-Duo, B25, B50, B50c, B71, MS28-Duo, Q19, Q21, Q22-Duo, Q88-Duo, QT7, S21, S22-Duo, T11, T12-Duo, T13-Duo, T22, T22-Duo, T23-Duo, T29-TV-Duo, T52, other
Nec: E101, E121, E122, N200, N208, N342i, N343i, N344i, N650i, N910, N916, N917, N919
Nerys: N330
NewGen: C1000, C610, C620, C650, C710, C800, E1000, E1100, E1200, Mars, S410, T1000
Nexian: G500, NX-G381i, NX-G503, NX-G505, NX-G522, NX-G700, NX-G788, NX-G801, NX-G868, NX-G900, NX-G901, NX-G911, NX-G922, NX-G923, NX-T780, NX-T900, NX-T911, other
NGM: Alittle, BlackAngel, DG689, Enjoy, Mito, Pixy, Vanity, Vanity-Touch, Vanity-Young, other
Nokia: 108, 1255, 130, 215, 220, 225, DCT4+
O2: Jet(J1), O2X1B, O2X1I, O2X2i, O2X3, O2X4, O2X7, O2XLI
Olive: VG200, VG300, VG3000, VG3100, VG3200, VG3201, VG400, VG500, VG800, VG8000, VGc800, other
Onida: C628, F830, F910, G430, G460, G520, G610, i501, V105, V110, V115, V140, W1110, other
Orange: Amsterdam, Dallas, Hollywood, Lisbon, Miami, Nalongo, Panama, Rio, Rome, San-Fransisco, Sydney, Tokyo, TR1, V101, Vegas
Orinoquia: G5580, G6600
Panasonic: A100, A101, A102, A200, A210, A500, Eluga, EZ180, EZ240, G50, G51E, G51M, G60, G70, GD55, GD67, GD68, MX6, MX7, P41, SA6, SA7, SC3, T40, VS2, VS3, VS6, VS7, X100, X200, X300, X400, X500, X60, X66, X68, X70, X700, X701, X77, ZE240
Pantech: C120, C180, C3, C320, C3B, C520-Breez-I, C530-Slate, C600, C610, C630, C740-Matrix, C790-Alladin-Duo, C810-Duo, C820-Matrix-Pro, G3900, G800, G900, GB300, P1010, P2000-Breeze-II, P2020-Ease, P2030, P5000, P6010, P7000-Impact, P7040-Link, P7040P, P8000-Crossover, P9020-Pursuit, P9050-Laser, P9060-Pocket, P9070-Burst, PG-1000, PG-1200, PG-1210, PG-1400, PG-1405, PG-1410, PG-1500, PG-1900, PG-3000, PG-3200, PG-3210, PG-3500, PG-3600, PG-3810, PG-6100, PG-C300, PN210
PCD: CL1133, CL1135, CL1136EN, CLX100PR, GLPF1114MX, GPF1134CA, GPFL1238CW, GTX212, TTX28MX
Philips: 192, 199, 290, 292, 298, 390, 568, 768, 960, CT7688, E100, E210, F322, F511, K700, M200, S200, S220, S308, S660, S800, S880, S890, W732, X100, X116, X170, X216, X223, X312, X325, X501, X503, X513, X518, X605, X620, X623, X703, X710, X800, X806, X830, Xenium-9@9u, Xenium-9@9w, other
PowerTel: M6000
QMobile: 117, 212, A10, A11, A110, A115, A12, A120, A15, A170, A2, A20, A290, A300, A34, A36, A50, A500, A51, A55, A5-Classic, A6, A60, A600, A610, A63, A65, A650, A7, A70, A700, A75, A750, A8, A80, A8i, A9, A900, A900i, A910, A950, A96, B100, B120, B170, B18, B25, B255, B260, B45, B5, B500, B55, B6, B60, B600, B65, B70, B8, B80, B800, B85, B90, C12, C3, E10, E100, E11, E120, E125, E150, E16, E18, E195, E20, E200, E4, E40, E400, E440, E5, E50, E500, E6, E60, E740, E750, E755, E760, E770, E775, E787i, E790, E8, E85, E850, E850+, E860, E880, E890, E9, E90, E900, E95, E990, F22, F220, F23, F252, F363, F55, F680, G175, G200, G220, G300, G400, i10, i12, i5, i5i, i6, i7, i9, LT150, M10, M2, M20, M22, M400, M450, M500, M550, M700, M80, M90, Max4, ME114, Noir, Q11, Q126, Q18, Q180, Q20, Q212, Q213, Q215, Q218, Q24, Q25, Q25i, Q26, Q266, Q26i, Q27, Q28, Q28i, Q29, Q33, Q37, Q38, Q3i, Q4, Q510, Q55, Q61, Q63, Q66, Q73, Q8, Q88, Q99, R1000, R200, R300, R350, R750, R800, S150, S200, S300, T550, T630, V2, V4, V5, W20, W200, X1, X100, X11, X150, X2, X200, X220, X225, X25, X250, X300, X35, X4, X400, X500, X550, X6, X60, X7, X70, X80, X800, X90, Z3, Z4, Z4-Mini, Z6, Z7, other
Rainbow-mts: S189
Reliance: Classic-7310, Classic-7610
Sagem: my150x, my220v, my220x, my225x, my226
Samsung: B300, B310E, C140, C140i, C260, C260M, C266, C300, E900, GT-E1200i, GT-E1200R, GT-E1202i, GT-E1207y, GT-E1270, GT-E1272, GT-E1280, GT-E1280T, GT-E1282T, GT-E2200, GT-E2202, SCH-B139, SCH-B189, SCH-B239, SCH-B259, SCH-B279, SCH-B309, SCH-B319, SCH-B379, SCH-B399, SCH-B619, SCH-E159, SCH-F302, SCH-F309, SCH-F679, SCH-S189, SCH-S229, SCH-S259, SCH-S269, SCH-S279, SCH-S299, SCH-S339, SCH-X609, X120, X140
Sendtel: EV530, Q800
SeniorPhone: 1055
SFR: 101, 1080, 111, 114, 115, 116, 118, 121, 122, 123, 132, 151, 195, 227, 228, 228FM, 231, 232, 241, 242, 251, 251-Messenger-Edition, 261, 341, 342, 343, 344, 3440, 522, Starnaute-Noir, StarTrail-Titanium
Siemens: AP75, CFX65, CL75, SFG75, ST55, ST60
Simoco: SM1000, SM1100, SM1200, SM234, SM298, SM322, SM366, SM377, SM399, SM466, SM488, SM498, SM499, SM611, SM633, SM700, SM966, SM988, SM999, other
Sitronics: SM8190, SM8290, SMD-104, SMD-105, other
Skyzen: EZ100, EZ1000, EZ200, EZ300, EZ400, EZ500, EZ600, EZ700, EZ800, Hummer-HT2, N101, S3, S6, S8, ST1
Sony-Ericsson: J100(i), J110a, J110i, J120i, J121i, J132, K200a, K200i, K205i, K220i, K330, R300, R306, T250i, T280i,

T303, Z250a, Z250i, Z320i
Spice: D80, D88, D88N, D90, M3636, M4242, M4250, M4580, M4580DV, M5006, M5020, M5021, M5032, M5050, M5151, M5161, M5161n, M5162, M5200N, M5208, M5249, M5251, M5252, M5351, M5355, M5361, M5367, M5370, M5371, M5373, M5377, M5389, M5396, M5403, M5406, M5408, M5430, M5454, M5566, M5611, M5916, M5917, M5918, M5920, M6000, M6060, M6110, M6111, M6262, M6363, M9010, M940, M940N, Mi-354, Mi-356, Mi-358, Mi-359, Mi-423, Mi-426, Mi-431, Mi-438, Mi-439, Mi-442, Mi-451, Mi-503, Mi-504, Mi-505, Mi-506, Mi-508, Mi-509, Mi-535, Mi-600, QT-44, QT-50, QT-52, QT-55, QT-58, QT75, S300, S400, S404, S404N, S410, S415, S450, S5, S500, S5110, S525, S530, S5330, S535, S540, S545, S555, S570, S580, S590, S600, S600N, S640, S650, S7, S700, S7000, S705, S707, S707n, S710, S8, S800, S808, S820, S9, S900, S920, S940, X1, other
TCL: 3188+, 3188M, 3188U, 718, 728, 738, A288, D569, D659, E330, GQ05, M361, M388, M530, M580, M586, M819, Q510, Q515, Q550, T106, T108, T550, T558, T766, T939, U58, U80, V18, V6, other
Tecno: D100, M280, MP3, ST600, ST880, T277, T330, T340, T342, T400, T570, T600, T7, T727, T800, T880, T950, V410, V500, V801, V90i, X200, X200i, X210, Y4, other
Telit: T200, T250
Tesco-Mobile: Mojo-Chat
Thomson: TH102, TN320, TN710
Tinno: E01c, HD100, S4031A, S5201, T500, T670, TV900, TV990, X66A+, other
TMN: 1210, 500, 5000, BlackStone, BlueBelt-I, BlueBelt-II, Easy, Sapo-A5, Script, SilverBelt, Softstone
T-Mobile: Affinity, Beat, E200-Vibe, Energy, Unity, Vairy-Touch, Vairy-Touch-II, Vivacity, X760, Zest
TOCS: C001, C64, C68, M52
Toshiba: TS10, TS30, TS608
TwinSim: T60, T99
UCall: M108
UFone: G3510, G5500, G6600, G7600
Uninor: G-S212, S212
Usha-Lexus: 2020B, 303B, 777B, 789B, 800B, 828B, 838B, 858B, 877B, UL2104, other
UTstarcom: C2011B, C620, CL1135, CL381EN, G520, GFM114CP, GLP138GT, GLP138GTN, GLPF1114MX, GLPL138MX, GLPL148SV, GPF1134CA, GPF198, GPFE1238, GPFE1258, GPFE128en, GPFL1238CW, GPFM1238, GPFM1238CL, GPPE1238CW, GPPE1238ENR, GPRS1328, GPRS568, GPRS748, GPRS749, GPRS758, GPRS778, GPRS779, GPT2085, GPT380EN, GSM708, GSM718, GSM719, GTX212, GTX212CA, TE1201SV, other
Vairy: Touch, Touch-II
Verykool: i115, i119, i121, i126s, i250, i270, i280, i300, i305, i405, i410, i500, i600, i603, i605, i700, i720, S353, T742
Viettel: 6216, V6202, V6206
Virgin: Fly-SX200, Lobster-485, Lobster-544, Lobster-575, MicroSnapper, VM621i, V-Slide, V-Touch
Vitel: TSM1, TSM2, TSM3, TSM4, TSM5m, TSM6
VK-Mobile: VG207, VK1500, VK180, VK200, VK200_unlock, VK2000, VK2010, VK2020, VK2030, VK207i, VK3100, VK4000, VK4500, VK500, VK518, VK520, VK530, VK540, VK550, VK560, VK570, VK580, VK700, VK800, VK900
Vodafone: 123, 1230, 1231, 125, 135, 145, 150, 225, 225FM, 226, 226FM, 227, 228, 235, 250, 252, 330FM, 331, 340, 345, 351, 541, 543, 547, 550, 553, 945, Indie
Voxtel: 1iD, 2iD, 3iD, BD50, BD60, RX11, RX600, RX800, V350, V50, V500, VS600, VS800
Xiaomi: HM-Note-1TD, Miui-V5
Zetta: A10
Zonda: 1075, 1075R, 1085, 1090, 1095, 1095R, 1099, G1840, G1860, G1880, Levis, MZ1, MZ2, MZ9, N2000, TF350, TF425, ZMax500, ZMCK870, ZMCK890, ZMCK895, ZMEM1120, ZMKN110, ZMTFTTV20, ZMTN600, ZMTN610, ZMTN615, ZMTN905, ZMUR300
Zong: A136, R221
ZTE: 123, 125, 195, 201, 2010, 202, 203, 204, 225, 225FM, 226, 227, 228, 231, 731, 7310, 7610, 811, A12, A12+, A136, A136G, A139, A15, A16, A201, A201+, A205, A205+, A206, A208, A211, A212, A213, A215, A215+, A261, A261+, A261FM, A292, A301, A316i, A35, A35FM, A36, A36+, A36FM, A37, A39, A5, A61, A611, A611+, A62, A62+, A66, A661, A68, A80, A831, A832, A833, A861, A931, A932, A933+, Amigo, Android, Blade, Blade-G2, Blade-Lux-Q, Blade-S, C310, C332, C335, C632, Carl, Coral-200, E400, E810, E821S, F120, G-F120, Global-Z3, G-N280, G-N281, G-N281-Negro, G-N290, G-N295, G-R220, G-R220-Lime, G-R221, G-R225, G-R230, G-R231, G-R235, G-R236, G-R236m, G-R620, Grand-X-Pro, G-S202, G-S212, G-S213, G-S215, G-S315, G-S516, G-T202, G-X671, G-X760, G-X930, G-X990, G-X991, H500, i766, i766CN, i799, LaPoste, Libra, Link, Maxx, Mercury, Monte-Carlo, Movistar-Class, Movistar-Link, Movistar-Prime, N261, N280, N281, N281-Negro, N285, N290, N295, N61, P726G, P729B, P729V, P733K, P733N, R220, R220-Lime, R221, R225, R228, R230, R231, R235, R236, R236m, R250, R3100, R620, R622, R630P, R631, R791, R830, Racer, Raise, Rio-II, Roamer, RTK-D1, S202, S202-VTecla, S212, S213, S215, S315, S315+, S316+, S511, S516, S518m, S521, Sage, SanFransisco-II, Skate, SmartFren-Wide, Smart-Netphone-701, Star-Addict, Star-Trail, T202, T28, Telstra-Smart-Touch-T3020, Tureis, Turksell-T1, U983, V170-Austria, V795, V816W, V852, V859, V875, V880, V880+, V889M, V960, V9-Tablet, WP626, X60, X630, X632, X670, X671, X730, X760, X760+KP, X761, X850, X876, X930, X960, X990, X991, XCD35, Xiang, Z990, other

Supported CDMA models:
Huawei: C2205, C2285, C506
Nokia: 1255
Motorola: C141c, W150, W150i, W170, W170C, W200, W210, W355
ZTE: Classic 201, 202, 203, 204, C335
Samsung: SCH-B139, SCH-B189, SCH-B239, SCH-B259, SCH-B279, SCH-B309, SCH-B319, SCH-B399, SCH-B619, SCH-E159, SCH-F302, SCH-F309, SCH-F679, SCH-S189, SCH-S229, SCH-S259, SCH-S269, SCH-S279, SCH-S299, SCH-S339, SCH-X609
Rainbow-mts: S189

Supported GSM Models - China market series

Complete contains:
- Infinity Box Dongle
Warranty
We offer 6 months of warranty for this product

É 2022 www.gsm-support.net